



**Where
Automation
Connects.**

Technical Note



MVI56(E)-MCMR Add-On Instruction Installation Guide

Modbus RTU/ASCII Serial Communication Module

Document Code: 33117

Author: ProSoft Technical Publications

Date: November 06, 2009



Asia Pacific

Malaysia Office

Phone: +603.7724.2080

asiapc@prosoft-technology.com

Languages spoken: Chinese, English, Japanese

China Office

Phone: +86.21.5187.7337

asiapc@prosoft-technology.com

Languages spoken: Chinese, English

Europe

France Office

Phone: +33 (0)5.34.36.87.20

support.emea@prosoft-technology.com

Languages spoken: French, English

Middle East and Africa

Phone: +971.(0)4.214.6911

mea@prosoft-technology.com

Languages spoken: English, Hindi

North America

California and Wisconsin Offices

Phone: +1 661.716.5100

support@prosoft-technology.com

Languages spoken: English, Spanish

Latin America

Brasil Office

Phone: +55.11.5083.3776

brasil@prosoft-technology.com

Languages spoken: Portuguese, English

Mexico and Central America Office

Phone: +52.222.3.99.6565

soporte@prosoft-technology.com

Languages spoken: Spanish, English

Regional Office

Phone: +1.281.298.9109

latinam@prosoft-technology.com

Languages spoken: Spanish, English

Document Information

Author	ProSoft Technical Publications
Description	Modbus RTU/ASCII Serial Communication Module
Date	November 06, 2009
Revision	2.02.001
Product Name	MVI56(E)-MCMR
Document Code	33117

ProSoft Technology

5201 Truxtun Ave., 3rd Floor
Bakersfield, CA 93309
+1 (661) 716-5100
+1 (661) 716-5101 (Fax)
www.prosoft-technology.com

Copyright © ProSoft Technology, Inc. 2009. All Rights Reserved.

November 06, 2009

ProSoft Technology ® ProLinX ®, inRAX ®, ProTalk®, and RadioLinX ® are Registered Trademarks of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

How to contact us: Sales & Support

All ProSoft Technology® products are backed with unlimited technical support. Contact our worldwide Technical Support team directly by phone or email:

Asia Pacific

+603.7724.2080, support.asia@prosoft-technology.com
Languages spoken include: Chinese, Japanese, English

Europe – Middle East – Africa

+33 (0) 5.34.36.87.20, support.EMEA@prosoft-technology.com
Languages spoken include: French, English
europe@prosoft-technology.com,
fax to +33 (0) 5.61.78.40.52

North America

+1.661.716.5100, support@prosoft-technology.com
Languages spoken include: English, Spanish
orders@prosoft-technology.com,
fax to +1 661.716.5101

Latin America (Sales only)

+1.281.298.9109, latinam@prosoft-technology.com
Languages spoken include: Spanish, English

Brasil

+55-11.5084.5178, eduardo@prosoft-technology.com
Languages spoken include: Portuguese, English

Contents

Document Information	2
ADD MODBUS RTU/ASCII SERIAL COMMUNICATION TO CONTROLLOGIX WITH AN ADD-ON INSTRUCTION FOR RSLOGIX® 5000 VERSION 16.....	4
Introduction	4
Instructions	5
Benefits.....	13

Add Modbus RTU/ASCII Serial Communication to ControlLogix with an Add-On Instruction for RSLogix® 5000 Version 16

In This Chapter

- ❖ Introduction 4
- ❖ Instructions 5
- ❖ Benefits 13

Introduction

Beginning with version 16 of RSLogix™ 5000 software, Rockwell Automation added an extremely helpful feature to make it easier than ever to set up third party modules, custom code, or proprietary code. They called this new feature an "Add-On Instruction" (AOI). This AOI feature allows third party vendors, panel builders, and system integrators to create ladder logic code that can be protected for safety or security reasons and can be locked to ensure that the code remains unchanged.

ProSoft Technology®'s inRAx® Modbus RTU/ASCII Serial Communication Module for ControlLogix®, the MVI56(E)-MCMR, is provided with an Add-On Instruction to allow easy integration of the module into new or existing RSLogix 5000 Version 16 and newer projects.

ProSoft Technology® has enhanced the MVI56(E)-MCMR module's Add-On Instruction in a way that will significantly simplify installation.

Now users can integrate the module into a new or existing project by importing a single ladder logic import file, as opposed to importing multiple User Defined Data Types and ladder logic rungs, one-by-one.


The entire ladder logic required by the MVI56(E)-MCMR is encapsulated in one, single Add-On Instruction. And, when the ladder logic .L5X file is imported, it automatically creates all the required User-Defined Data Types, Controller Tags, and the Add-On Instruction logic, all while adding the preconfigured AOI instruction to the ladder rung.




This new way of importing an AOI as a completed ladder rung enables quicker and easier integration of the MVI56(E)-MCMR with fewer chances for human typographical errors and ladder coding or setup errors.

Instructions

- 1 Open the **FILE** menu, and then choose **NEW...**




- 2 Select your ControlLogix controller model.
- 3 Select **REVISION 16**.
- 4 Enter a name for your controller, such as "My_Controller".
- 5 Select your ControlLogix chassis type.
- 6 Select **SLOT 0** for the controller.




Next, create the network.

- 1 Right-click **I/O CONFIGURATION** and choose **NEW MODULE...**




- 2 Expand the **COMMUNICATIONS** module selections and then select the Ethernet Bridge module that matches your hardware. This example uses a 1756-ENBT/A module.




Note: If you are prompted to "Select Major Revision", choose the lower of the available revision numbers.

- 3 Name the ENBT/A module, then set the IP Address and slot location in the local rack with the ControlLogix processor.




- 4 Click **OK**.
- 5 Next, select the **1756-ENBT** module that you just created in the Controller Organization pane and click the right mouse button to open a shortcut menu. On the shortcut menu, choose **NEW MODULE**.




- 6 Repeat steps 2 and 3 to add the second EtherNet/IP module to the remote rack.


- 7 Select the remote **1756 BACKPLANE** node in the Controller Organization pane underneath the remote rack EtherNet/IP module you just created and click the right mouse button to open a shortcut menu. On the shortcut menu, choose **NEW MODULE**.



This action opens the **SELECT MODULE** dialog box.




- 8 Select the **1756-MODULE (GENERIC 1756 MODULE)** from the list and click **OK**. This action opens the **NEW MODULE** dialog box.




9 Set the Module Properties values as follows:

Parameter	Value
Name	Enter a module identification string. The recommended value is MCMR, as this name will be linked automatically with the MSG paths, irrespective of the slot location.
Description	Enter a description for the module. Example: ProSoft communication module for Modbus Serial protocol communications.
Comm Format	Select DATA-INT (<i>*Very Important*</i>)
Slot	Enter the slot number in the rack where the MVI56(E)-MCMR module is to be installed.
Input Assembly Instance	1
Input Size	42
Output Assembly Instance	2
Output Size	42
Configuration Assembly Instance	4
Configuration Size	0


10 On the **CONNECTION** tab, set the **RPI** value for your project. Fifty (50) milliseconds is usually a good starting value.




The **MVI56(E)-MCMR** module is now visible in the **I/O CONFIGURATION** section




- 11 In the **CONTROLLER ORGANIZATION** window, expand the **TASKS** folder and subfolder until you reach the **MAINPROGRAM** folder.
- 12 In the **MAINPROGRAM** folder, double-click to open the **MAINROUTINE** ladder.
- 13 Select an empty rung in the new routine, and then click the right mouse button to open a shortcut menu. On the shortcut menu, choose **IMPORT RUNG...**




- 14 Navigate to the location on your PC where you saved the Add-On Instruction (for example, "My Documents" or "Desktop"). Select the **MVI56(E)MODBUS RTU/ASCII SERIAL_ADDON_RUNG_<VERSION #>.L5X** file




This action opens the **IMPORT CONFIGURATION** dialog box, showing the controller tags that will be created.




- If you are using the module in a different slot (or remote rack), select the correct connection input and output variables that define the path to the module. If your module is located in Slot 1 of the local rack, this step is not required.



16 Click **OK** to confirm the import. RSLogix will indicate that the import is in progress:



When the import is completed, the new rung with the Add-On Instruction will be visible as shown in the following illustration.



The procedure has also imported new User Defined Data Types, Controller Tags, and the Add-On instruction for your project.



17 Save the application and then download the sample ladder logic into the processor.

Benefits

This process for importing the MVI56(E)-MCMR Add-On Instruction into the RSLogix ladder logic file has replaced the practice of importing User Defined Data Types and multiple rungs of ladder in multiple ladder files.

This enhancement allows you to easily integrate the module into a new or existing RSLogix project without manually copying over each file. Doing so practically eliminates human typographical errors. Additionally, errors that do occur are significantly easier to correct.