

Appendix A: DF1 Command Support

FUNCTION CODE #1 Protected Write (Basic Command Set)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 1 | Protected Write Function | |
| 8 | Word Address | Word address where to start the write operation. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to write one or more words of data into a limited area of the slave device. This function should work on the following devices: 1774-PLC, PLC-2, PLC-3, PLC-5 and PLC-5/250.

FUNCTION CODE #2 Unprotected Read (Basic Command Set)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled and 1=Continuous. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 2 | Unprotected Read Function | |
| 8 | Word Address | Word address where to start the read operation. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to read one or more words of data from the PLC memory. This function should work on the following devices: 1774-PLC, PLC-2, PLC-3, PLC-5, SLC 500, SLC 5/03, SLC 5/04 and MicroLogix 1000.

FUNCTION CODE #3
Protected Bit Write (Basic Command Set)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|---|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address for the data to be associated with the command. The address defined represents a register address and not a bit address. This function will update one or more words of data as defined by the count parameter. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: Always zero (0). | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 3 | Protected Bit Write Function | |
| 8 | Word Address | Word address where to start the write operation. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to set or reset individual bits within a limited area of the PLC data table. This function should work on the following devices: 1774-PLC, PLC-2, PLC-3, PLC-5 and PLC-5/250.

FUNCTION CODE #4
Unprotected Bit Write (Basic Command Set)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|---|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address for the data to be associated with the command. The address defined represents a register address and not a bit address. This function will update one or more words of data as defined by the count parameter. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: Always zero (0). | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 4 | Unprotected Bit Write Function | |
| 8 | Word Address | Word address where to start the write operation. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to set or reset individual bits within a limited area of the PLC data table. This function should work on the following devices: 1774-PLC, PLC-2, PLC-3 and PLC-5.

FUNCTION CODE #5
Unprotected Write (Basic Command Set)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 5 | Unprotected Write Function | |
| 8 | Word Address | Word address where to start the write operation. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to write one or more words of data to the PLC memory. This function should work on the following devices: 1774-PLC, PLC-2, PLC-3, PLC-5, SLC 500, SLC 5/03, SLC 5/04 and MicroLogix 1000.

FUNCTION CODE #100
Word Range Write (PLC-5 Command)(Binary Address)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|---|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 100 | Word Range Write Command. | |
| 8 | File Number | PLC-5 file number to be associated with the command. If a value of -1 is entered for the parameter, the field will not be used in the command, and the default file will be used. | P1 |
| 9 | Element Number | The parameter defines the element in the file where write operation will start. If a value of -1 is entered for the parameter, the field will not be used in the command, and the default element will be used. | P2 |
| 10 | Sub-Element Number | This parameter defines the sub-element to be used with the command. Refer to the AB documentation for a list of valid sub-element codes. If the value is set to 1, the default sub-element number will be used. | P3 |
| 11 | Not Used | This field is not used by the command. Values entered in this column will be ignored. | P4 |

This function is used to write one or more words of data to a PLC data table. This function should work on the following devices: PLC-5.

FUNCTION CODE #101
Word Range Read (PLC-5 Command)(Binary Address)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled and 1=Continuous. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 101 | Word Range Write Command. | |
| 8 | File Number | PLC-5 file number to be associated with the command. If a value of -1 is entered for the parameter, the field will not be used in the command, and the default file will be used. | P1 |
| 9 | Element Number | The parameter defines the element in the file where write operation will start. If a value of -1 is entered for the parameter, the field will not be used in the command, and the default element will be used. | P2 |
| 10 | Sub-Element Number | This parameter defines the sub-element to be used with the command. Refer to the AB documentation for a list of valid sub-element codes. If the value is set to -1, the default sub-element number will be used. | P3 |
| 11 | Not Used | This field is not used by the command. Values entered in this column will be ignored. | P4 |

This function is used to read one or more words of data from a PLC data table. This function should work on the following devices: PLC-5.

FUNCTION CODE #102
Read-Modify-Write (PLC-5 Command)(Binary Address)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address for the data to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: Always zero (0). | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 102 | Read-Modify-Write Command. | |
| 8 | File Number | PLC-5 file number to be associated with the command. If a value of -1 is entered for the parameter, the field will not be used in the command, and the default file will be used. | P1 |
| 9 | Element Number | The parameter defines the element in the file where write operation will start. If a value of -1 is entered for the parameter, the field will not be used in the command, and the default element will be used. | P2 |
| 10 | Sub-Element Number | This parameter defines the sub-element to be used with the command. Refer to the AB documentation for a list of valid sub-element codes. If the value is set to -1, the default sub-element number will be used. | P3 |
| 11 | Not Used | This field is not used by the command. Values entered in this column will be ignored. | P4 |

This function is used to write one or more words of data to a PLC data table. This function should work on the following devices: PLC-5. The command constructed contains an AND mask and an OR mask. Values in the AND mask have the following definitions: 0=Reset and 1=Leave the Same. Values in the OR mask have the following definitions: 0=Leave the Same and 1=Set. The module is responsible for setting the mask values to correctly construct the message from the virtual database values.

FUNCTION CODE #150
Word Range Write (PLC-5 Command)(ASCII Address)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 150 | Word Range Write Command. | |
| 8 | File String | PLC-5 address as specified as an ASCII string. For example, N10:300. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to write one or more words of data to a PLC data table. This function should work on the following devices: PLC-5.

FUNCTION CODE #151
Word Range Read (PLC-5 Command)(ASCII Address)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled and 1=Continuous. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 151 | Word Range Read Command. | |
| 8 | File String | PLC-5 address as specified as an ASCII string. For example, N10:300. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to read one or more words of data from a PLC data table. This function should work on the following devices: PLC-5.

FUNCTION CODE #152
Read-Modify-Write (PLC-5 Command)(ASCII Address)

| Column | Command Parameter | Description | Parameter |
|---------|--------------------------|---|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address for the data to be associated with the command. The first database register is used as the AND mask for the command, and the second is used for the OR mask. Values in the AND mask have the following definitions: 0=Reset and 1=Leave the Same. Values in the OR mask have the following definitions: 0=Leave the Same and 1=Set. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: Always zero (0). | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 152 | Read-Modify-Write Command. | |
| 8 | File String | PLC-5 address as specified as an ASCII string. For example, N10:300. | P1 |
| 9 to 11 | Not Used | These fields are not used by the command. Values entered in these columns will be ignored. | P2 to P4 |

This function is used to write one or more words of data to a PLC data table. This function should work on the following devices: PLC-5. The command constructed contains an AND mask and an OR mask. Values in the AND mask have the following definitions: 0=Reset and 1=Leave the Same. Values in the OR mask have the following definitions: 0=Leave the Same and 1=Set. The module is responsible for setting the mask values to correctly construct the message from the virtual database values.

FUNCTION CODE #501
Protected Typed Logical Read (Two Address Fields)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled and 1=Continuous. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 501 | Logical Read Command | |
| 8 | File Type | SLC file type letter as used in file name string. Valid values for the system are N, S, F, A, | P1 |
| 9 | File Number | SLC file number to be associated with the command. | P2 |
| 10 | Element Number | The parameter defines the element in the file where write operation will start. | P3 |
| 11 | Not Used | This field is not used by the command. Values entered in this column will be ignored. | P4 |

This function is used to read one or more words of data from a PLC data table.

FUNCTION CODE #502
Protected Typed Logical Read (Three Address Fields)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled and 1=Continuous. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 502 | Logical Read Command | |
| 8 | File Type | SLC file type letter as used in file name string. Valid values for the system are N, S, F, A, | P1 |
| 9 | File Number | SLC file number to be associated with the command. | P2 |
| 10 | Element Number | The parameter defines the element in the file where write operation will start. | P3 |
| 11 | Sub-Element Number | This parameter defines the sub-element to be used with the command. Refer to the AB documentation for a list of valid sub-element codes. | P4 |

This function is used to read one or more words of data from a PLC data table. This function should work on the following devices: SLC 500, SLC 5/03 and SLC 5/04.

FUNCTION CODE #509
Protected Typed Logical Write (Two Address Fields)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 509 | Logical Write Command | |
| 8 | File Type | SLC file type letter as used in file name string. Valid values for the system are N, S, F, A, | P1 |
| 9 | File Number | SLC file number to be associated with the command. | P2 |
| 10 | Element Number | The parameter defines the element in the file where write operation will start. | P3 |
| 11 | Not Used | This field is not used by the command. Values entered in this column will be ignored. | P4 |

This function is used to write one or more words of data to a PLC data table.

FUNCTION CODE #510
Protected Typed Logical Write (Three Address Fields)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the first data point to be associated with the command. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: 0=None, 1=Swap words, 2=Swap words & bytes and 3=swap bytes in each word. | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 510 | Logical Write Command | |
| 8 | File Type | SLC file type letter as used in file name string. Valid values for the system are N, S, F, A, | P1 |
| 9 | File Number | SLC file number to be associated with the command. | P2 |
| 10 | Element Number | The parameter defines the element in the file where write operation will start. | P3 |
| 11 | Sub-Element Number | This parameter defines the sub-element to be used with the command. Refer to the AB documentation for a list of valid sub-element codes. | P4 |

This function is used to write one or more words of data to a PLC data table. This function should work on the following devices: SLC 500, SLC 5/03 and SLC 5/04.

FUNCTION CODE #511
Protected Typed Logical Write with Mask (Three Address Fields)

| Column | Command Parameter | Description | Parameter |
|--------|--------------------------|--|-----------|
| 1 | Enable/Type Word | 0=Disabled, 1=Continuous and 2=Conditional. | |
| 2 | Virtual Database Address | This parameter defines the database address of the data to be associated with the command. The first word of data contains the bit mask and the second word contains the data. | |
| 3 | Poll Interval | Minimum number of seconds to wait before polling with this command. | |
| 4 | Count | Number of data word values to be considered by the function. | |
| 5 | Swap Type Code | Swap type code for command: Always zero (0). | |
| 6 | Node Address | Address of unit to reach on the data highway. | |
| 7 | Function Code = 511 | Logical Write with mask | |
| 8 | File Type | SLC file type letter as used in file name string. Valid values for the system are N, S, F, A, | P1 |
| 9 | File Number | SLC file number to be associated with the command. | P2 |
| 10 | Element Number | The parameter defines the element in the file where write operation will start. | P3 |
| 11 | Sub-Element Number | This parameter defines the sub-element to be used with the command. Refer to the AB documentation for a list of valid sub-element codes. | P4 |

This function is used to write one or more words of data from a PLC data table controlling individual bits in the table. The bit mask used for the command is 0xFFFF. This provides direct manipulation of the data in the device with the internal data of the module. The function requires that all data associated with the command use the same mask.