

### 1 DESCRIPTION

The Modbus TCP/IP Driver allows the FieldServer to transfer data to and from devices over Ethernet using Modbus TCP/IP Protocol. The Modbus TCP/IP driver uses port 502. This port is configurable. The driver was developed for Modbus Application Protocol Specification V1.1a" from Modbus-IDA. The specification can be found at [www.modbus.org](http://www.modbus.org). The FieldServer can emulate both a Client and a Server simultaneously on the same Ethernet port. When configured as a client, the Modbus TCP/IP driver can send up to 10 concurrent polls. Supports Modbus TCP/IP broadcasts and Modbus TCP/IP multiple server messages.

The information that follows describes how to expand upon the factory defaults provided in the configuration files included with the FieldServer.

There are various register mapping models being followed by various vendors. To cover all these models FieldServer uses the following three Models:

- **Modicon\_5digit** – Use this format where addresses are defined in 0xxxx, 1xxxx, 3xxxx or 4xxxx format. A maximum of 9999 registers can be mapped of each type. This is FieldServer driver's default format.
- **ADU** – Application Data Unit address. Use this format where addresses of each type are defined in the range 1-65536.
- **PDU** – Protocol Data unit address. Use this format where addresses of each type are defined in the range 0-65535.

The key difference between ADU and PDU is for example if Address\_Type is ADU and address is 1, the driver will poll for register 0. If Address\_Type is PDU, the driver will poll for address 1.

**Note 1:** If vendor document shows addresses in extended Modicon (i.e. 6 digit) format like 4xxxxx then consider these addresses as xxxxx (omit the first digit) and use either ADU or PDU.

**Note 2:** The purpose of providing 3 different ways of addressing the Modbus registers is to allow the user to choose the addressing system most compatible with the address list being used. At the protocol level, the same protocol specification is used for all three with the exception of the limited address range for Modicon\_5digit.

### 1.1 Connection Facts

FieldServer Mode	Nodes	Comments
Client	1	Only 1 client node allowed on Multidrop systems.
Server	255	Actual electrical loading may reduce number of usable Server nodes.

### 2 FORMAL DRIVER TYPE

Ethernet

Client or Server

### 3 COMPATIBILITY

FieldServer Model	Compatible
FS-B35 Series	Yes
ProtoNode/ProtoAir	Yes
QuickServer FS-QS-10xx	Yes
QuickServer FS-QS-12xx	Yes
QuickServer FS-QS-20xx	Yes
QuickServer FS-QS-22xx	Yes

### 4 CONNECTION INFORMATION

Connection Type: Ethernet

Ethernet Speeds Supported: 10Base-T, 100Base-T

### 5 DEVICES TESTED

Device	Tested (FACTORY, SITE)
Quantum PLCs	Customer
Fix Intellution	Factory
Wonderware Intouch	Factory
GE Cimplicity	Customer
Others	Contact factory

## 6 COMMUNICATION FUNCTIONS

### 6.1 Data Types Supported

Data Type	Comments
ASCII	8-bit character
Digital	Digital
Float	32-bit IEEE floating point
Long	Unsigned 32-bit integer
Signed	Signed 16-bit integer
Slong	Signed 32-bit integer
Unsigned	Unsigned 16-bit integer
Input_Reg_64bit	Long input data type
64Bit_Reg	Long data type
Input_Double	Double-precision 64-bit IEEE 754 floating point input data type
Double_Reg	Double-precision 64-bit IEEE 754 floating point data type

### 6.2 Function Codes Supported

Function Codes	Description
01	Read Discrete Output Status (0xxxx)
02	Read Discrete Input Status (1xxxx)
03	Read Output Registers (4xxxx)
04	Read Input Registers (3xxxx)
05	Force Single Coil (0xxxx)
06	Preset Single Register (4xxxx)
15	Force Multiple Coils (0xxxx)
16	Preset Multiple Registers (4xxxx)
17	Report Slave ID
EX	Exception Status
FF	FIFO